

## Dräger PARAT® C Fire Escape Hood

A fire along with the hazardous smoke and fumes it gives off can take you by surprise. The Dräger PARAT® C Fire Escape Hood is designed to help you escape fire safely by filtering out toxic smoke and fumes – allowing you to breathe safely for a minimum of 15 minutes while escaping to a safe environment.



ST-1586-2003

For years, fire escape hoods have been installed and used during emergencies in hospitals, nursing homes, industrial sites, and even ships. Fire departments use them when rescuing people from burning buildings. The Dräger PARAT® C fire escape hood protects its wearers for a minimum of 15 minutes from hazardous fumes and gases which are produced during a fire. Its filter is highly efficient in filtering out carbon monoxide and other fire related gases, fumes and particles.

The specially designed hood of the PARAT® C provides protection against flying sparks and allows bearded users and spectacle wearers a safe escape. Due to the universal size of the hood and inner half mask the PARAT® C fits almost everyone.

Escaping from a fire leaves you no time for blurred vision. The Dräger large visor is treated with an anti-fog coating which keeps your field of vision clear during the escape.

According to your application you can choose from five different packaging options of the Dräger PARAT® C: an environmentally friendly cardboard single pack, the soft pack easy to take along, the traveller pack in a well-protected plastic case, the heavy-duty box tried and tested in heavy industry, or the twin-pack, which holds two escape hoods in a transparent wall mounted box.

### Benefits:

- Highly visible hood in a universal size with a flexible neck seal
- Wide, anti-fog coated visor for a clear view during an escape.
- Highly efficient filter protects from toxic gases, fumes and particles, which are produced during a fire
- Five different packaging variations – the right option for every environment.

Dräger PARAT® C – another quality product from Dräger.



ST-2418-2003

**Dräger PARAT® C**  
Fire escape hood



ST-270-2002

**Dräger PARAT® C**  
Soft-Pack

**TECHNICAL DATA**

Filter performance:	Combination cartridge (gas & particle filter) provides protection against smoke, gases and particles, Filter Type: CO-P2
Approved duration:	minimum of 15 minutes
Service Life:	12 years total (6 years maintenance free – 1 filter and valve change required after 6 years)
Weight:	approx. 600 grams
Dimensions:	Dräger PARAT C Single-, Traveller-, Soft-Pack: 8 x 19 x 13,5 cm (H x L x W) Dräger PARAT C Box: 18 x 19 x 8 cm (H x L x W) Dräger PARAT C Twin-Pack: 9 x 33 x 22,5 cm (H x L x W)
Approval	CE mark, tested according to EN 403

**ORDER INFORMATION**

Dräger PARAT C Single-Pack, in a compact cardboard box	R 52 817
Dräger PARAT C Traveller-Pack, in a sturdy plastic case	R 52 818
Dräger PARAT C Soft-Pack, in a handy carrying case	R 53 555
Dräger PARAT C Box, tried and tested by heavy industries	R 54 461
Dräger PARAT C Twin-Pack, two escape hoods in a transparent wall-mounted box	R 52 845
Dräger PARAT training hood	R 54 105
Replacement filter PARAT C (CO-P2)	67 36 192
Spare part set (exhalation valve and filter strip)	R 25 266
Wall holder for the Dräger PARAT C Traveller-Pack	R 51 906
Harness for wearing the Dräger PARAT C Traveller-Pack on the belt	R 53 205
Carrying shoulder strap for the R 53 205	R 53 783
Hip strap for the R 53 205	R 53 026
Hip strap for the PARAT® C Box R54461	67 33 934
Carrying bag for 2 PARAT® C Single- or Traveller-Packs	R 51 907

**Dräger Safety AG & Co. KGaA**

Revalstrasse 1  
23560 Lübeck, Germany  
Tel +49 451 882-0  
Fax +49 451 882-2080

[www.draeger.com](http://www.draeger.com)

**SUBSIDIARIES****AUSTRALIA**

Draeger Safety Pacific Pty. Ltd.  
Axxess Corporate Park  
Mt. Waverley, Vic 3149  
Tel +61 3 92 65 50 00  
Fax +61 3 92 65 50 95

**CANADA**

Draeger Canada Ltd.  
7555 Danbro Crescent  
Mississauga, Ontario L5N 6P9  
Tel +1 905 821 8988  
Fax +1 905 821 2565

**P. R. CHINA**

Beijing Fortune Draeger  
Safety Equipment Co., Ltd.  
Beijing 101300  
Tel +86 10 80 49 80 00  
Fax +86 10 80 49 80 05

**FRANCE**

Draeger Industrie S.A.S.  
3c, Route de la Fédération  
67025 Strasbourg Cedex  
Tel +33 388 40 76 76  
Fax +33 388 40 76 67

**MEXICO**

Draeger Safety S.A. de C.V.  
Av. Peñuelas No. 5  
Querétaro, Qro México  
Tel +52 442 246 1113  
Fax +52 442 246 1114

**NETHERLANDS**

Dräger Safety Nederland B.V.  
Edisonstraat 53  
2700 AH Zoetemeer  
Tel +31 79 344 46 66  
Fax +31 79 344 47 90

**SINGAPORE**

Draeger Safety Asia Pte. Ltd.  
67 Ayer Rajah Crescent # 06 03  
139950 Singapore  
Tel +65 68 72 92 88  
Fax +65 67 73 20 33

**REP. OF SOUTH AFRICA**

Dräger South Africa (Pty) Ltd.  
P.O.Box 68601  
Bryanston 2021  
Tel +27 11 465 99 59  
Fax +27 11 465 69 53

**SPAIN**

Draeger Safety Hispania S.A.  
Calle Xaudaró 5  
28034 Madrid  
Tel +34 91 358 02 44  
Fax +34 91 729 48 99

**UNITED KINGDOM**

Draeger Safety UK Ltd.  
Blyth Riverside Business Park  
Blyth, Northumberland NE24 4RG  
Tel +44 1670 352 891  
Fax +44 1670 356 266

**USA**

Draeger Safety, Inc.  
101 Technology Drive  
Pittsburgh, PA 15275  
Tel +1 412 787 8383  
Fax +1 412 787 2207