

Dräger PSS® 7000 with Dräger Bodyguard® 7000

Developed by professionals for professionals the new Dräger PSS® 7000 breathing apparatus – with Dräger Bodyguard® 7000 electronic monitoring unit – represents a major leap forward in the evolution of breathing apparatus for the professional fire fighter.



DRÄGER PSS® 7000

The Dräger PSS® 7000 is the platform and centre piece for a complete personal safety system for the fire fighter.

- Modular electronic monitoring system featuring the new Dräger Bodyguard® 7000, and options such as the Dräger FPS® Head-Up Display and Dräger PSS® 7000 Merlin modem for telemetry operation
- New high wear resistant comfort shoulder and waistbelt padding with antislip surface for good grip
- Sliding and pivoting waistbelt assembly
- 3-point height adjustment
- Breathing hoses integrated into the backplate prevent snagging and offer good hose protection
- Reflective and photoluminescent hose sleeves for improved visibility and additional hose protection
- Quick release pneumatics and shoulder and waistbelt assemblies for easy service and maintenance
- Option of new cylinder quick-connect for quick cylinder changeout in the field and in the workshop

DRÄGER BODYGUARD® 7000

The Dräger Bodyguard® 7000 is an electronic signal and warning unit

which provides continuous monitoring of personal information and operational status of the Dräger PSS® 7000 the self contained breathing apparatus.

The revolutionary ergonomic design of the Dräger Bodyguard® 7000 incorporates the pressure sensor and power supply modules into the backplate of the Dräger PSS® 7000 which results in a balanced distribution of weight and a compact lightweight electronic monitoring unit.

Features

- Integrated ADSU and Distress signaling
- Visual & Acoustic Warnings and Alarms
- Easy Push Button Operation
- Digital and Analogue Display of Cylinder Pressure
- User Configurable
- Enhanced display with text scrolling
- Automatic Self Tests & System Tests
- Datalog with personal ID
- PC Link Software
- Time to Whistle
- Choice of Operating Modes
- Choice of power supply modules
- New lightweight user friendly design

Dräger PSS® 7000 – another quality product from Dräger.



ST-6147-2007

Dräger PSS® 7000
State of the art breathing apparatus with Dräger Bodyguard® 7000 electronic monitoring unit



TECHNICAL DATA

	Dräger PSS® 7000 Pneumatic Gauge	Dräger PSS® 7000 Bodyguard
Weight of complete set with Dräger FPS® 7000 facemask, lung demand valve and Dräger 6.8 litre carbon composite cylinder (20 year design life)	11.7 kg	12.2 kg
Input pressure (bar)	0–300	0–300
Normal 1st stage output pressure	7.5 bar	7.5 bar
1st stage output flow (l/min)	> 1000	> 1000
Pneumatic warning whistle activation pressure	50–60 bar	50–60 bar
Pneumatic whistle sound Level (dBA)	> 90	> 90
ADSU Main Alarm	N/A	102 to 112 dBA measured at 250 mm (JCDD 38 revision)
Battery (5 x AA battery pack)	N/A	> 365 hrs normal use
Operating Temperature °C	–30 – +60	–30 – +60
Approvals		
Breathing Apparatus	EN 137: 2006 Type 2, vfdb 0802	EN 137: 2006 Type 2, vfdb 0802
Intrinsic safety	ATEX 94/9/EC classification is I M1/II 1G IIC T6 (Ta = –30°C to +60°C)*	ATEX 94/9/EC classification is I M1/II 1GD EEx ia I/IIC T4 (Ta = –30°C to +60°C)*
Electromagnetic Compatibility	N/A	EN 61000-6-2
Radiation Emissions	N/A	EN 50081-1*

The above ATEX classifications for Dräger PSS® 7000 are limited to certain breathing apparatus configurations only and there are exceptions to the categories. Please consult Dräger for details.

ORDER INFORMATION

Dräger PSS® 7000 Modular Upgrades/Accessories	Order No
Dräger FPS® 7000 HUD In-Mask display	33 56 555
Dräger PSS® 7000 AA battery pack (set of 5 batteries included)	33 56 556
Dräger PSS® 7000 PC Link Module (incl. PC Link Software)	33 56 560
Dräger PSS® 7000 Personal ID Cards (pack of 10)	33 56 561
Second LDV connection/female decontamination hose w LF coupling	33 55 748
Decontamination hose male	33 55 749
T-Piece (for 2 x 6.8 liter 300 bar carbon composite cylinders)	33 37 660
Dräger PSS® 7000 2nd Supply hose (male and female couplings)	33 56 530
Dräger PSS® 7000 Airline Kit w ASOV (QR) Occasional Use	33 55 844
Retaining Clip (Gauge/Bodyguard)	33 52 089
Waistbelt Loop	33 34 968
LDV Holder/Gauge/Bodyguard (push-in)	33 39 633
Cheststrap	33 39 280
Dräger PSS® Rescue Hood	33 54 982
BA Set Hardshell Carrying Case (orange)	33 35 412
BA Holdall Carrying Bag	33 56 473

SELECTED ACCESSORIES/UPGRADES



ST-6188-2007

Dräger Bodyguard® 7000



ST-9475-2006

Dräger FPS® 7000



ST-9907-2006

Dräger FPS® 7000
Head-Up Display



ST-6003-2006

Mechanical Gauge



ST-6005-2006

Plus LDV



ST-6165-2007

Cylinder Quick Connect



ST-6175-2007

AA Battery module



ST-6183-2007

Dräger PSS® 7000
secondary supply hose



ST-6184-2007

Airline Belt manifold
with ASV

ORDER INFORMATION

Dräger PSS® 7000 Compressed Air Breathing Apparatus			Description	Order No
Dräger	DIN Cyl. Thread	Single Cyl. Strap	Dräger PSS® 7000 SCS	33 55 068
Pneumatic Gauge	Connection	Univ. Cyl. Strap	Dräger PSS® 7000 TCS	33 55 930
	Cylinder Quick Connect	Single Cyl. Strap	Dräger PSS® 7000 QC SCS	33 56 542
Dräger PSS® 7000 Button	DIN Cyl. Thread	Single Cyl. Strap	Dräger PSS® 7000 BG7000 SCS	33 56 551
Dräger	Connection	Univ. Cyl. Strap	Dräger PSS® 7000 BG7000 TCS	33 56 552
Bodyguard® 7000	Cylinder Quick Connect	Single Cyl. Strap	Dräger PSS® 7000 BG7000 QC SCS	33 56 553
Tally	DIN Cyl. Thread	Single Cyl. Strap	Dräger PSS® 7000 BG7000 T SCS	33 56 679
	Connection	Univ. Cyl. Strap	Dräger PSS® 7000 BG7000 T TCS	33 56 680
	Cylinder Quick Connect	Single Cyl. Strap	Dräger PSS® 7000 BG7000 T QC SCS	33 56 825
Dräger PSS® 7000 Pneumatic Gauge (customizable)				33 55 850
Dräger PSS® 7000 Bodyguard (customizable)				33 56 567
Lung Demand Valves approved for use with Dräger PSS® 7000 Compressed Air Breathing Apparatus				
Plus LDV Short Hose Push in				33 38 700
Plus LDV Short Hose M45				33 38 706
Plus LDV Short Hose M40				33 50 501
Plus LDV M40 1.75m (rescue only)				33 50 606
Plus LDVs with special polymer diaphragm for use in H2S environments				
Plus LDV Short Hose Push in				33 38 967
Plus LDV Short Hose M45				33 38 968
Plus LDV Short Hose M40				33 38 969

Dräger Safety AG & Co. KGaA
 Revalstrasse 1
 23560 Lübeck, Germany
 Tel +49 451 882-0
 Fax +49 451 882-2080
 www.draeger.com

P. R. CHINA
 Beijing Fortune Draeger
 Safety Equipment Co., Ltd.
 Beijing 101300
 Tel +86 10 80 49 80 00
 Fax +86 10 80 49 80 05

NETHERLANDS
 Dräger Safety Nederland B.V.
 Edisonstraat 53
 2700 AH Zoetermeer
 Tel +31 79 344 46 66
 Fax +31 79 344 47 90

SPAIN
 Draeger Safety Hispania S.A.
 Calle Xaudaró 5
 28034 Madrid
 Tel +34 91 728 34 00
 Fax +34 91 729 48 99

SUBSIDIARIES

AUSTRALIA
 Draeger Safety Pacific Pty. Ltd.
 Axxess Corporate Park
 Mt. Waverley, Vic 3149
 Tel +61 3 92 65 50 00
 Fax +61 3 92 65 50 95

FRANCE
 Dräger Safety France S.A.S.
 3c, Route de la Fédération
 67025 Strasbourg Cedex
 Tel +33 388 40 76 76
 Fax +33 388 40 76 67

SINGAPORE
 Draeger Safety Asia Pte. Ltd.
 67 Ayer Rajah Crescent # 06 03
 139950 Singapore
 Tel +65 68 72 92 88
 Fax +65 67 73 20 33

UNITED KINGDOM
 Draeger Safety UK Ltd.
 Blyth Riverside Business Park
 Blyth, Northumberland NE24 4RG
 Tel +44 1670 352 891
 Fax +44 1670 356 266

CANADA
 Draeger Canada Ltd.
 7555 Danbro Crescent
 Mississauga, Ontario L5N 6P9
 Tel +1 905 821 8988
 Fax +1 905 821 2565

MEXICO
 Draeger Safety S.A. de C.V.
 Av. Peñuelas No. 5
 Querétaro, Qro México
 Tel +52 442 246 1113
 Fax +52 442 246 1114

REP. OF SOUTH AFRICA
 Dräger South Africa (Pty) Ltd.
 P.O.Box 68601
 Bryanston 2021
 Tel +27 11 465 99 59
 Fax +27 11 465 69 53

USA
 Draeger Safety, Inc.
 101 Technology Drive
 Pittsburgh, PA 15275
 Tel +1 412 787 8383
 Fax +1 412 787 2207